


Identifier Service SH	<h1>Service Document</h1>	
<h2>I-S-40-01 - How to enter License Code in VPC 40</h2>		Römerstr. 21 D – 71296 Heimsheim Tel.: + 49(0)7033-309878-41 service@schultheiss-gmbh.de http://www.schultheiss-gmbh.de

Apply for:

Machine Type	Version	Year
VPC 40	Since release	



Problem


- How to enter License Code in VPC 40
- **SCHULTH** error appears on the screen



Prerequisites


Get the License code by sending the Email at service@schultheiss-gmbh.de or orders@schultheiss-gmbh.de or sales@schultheiss-gmbh.de





Procedure

- Switch ON the machine
- Wait until the Self-test is completed
- Press  'M' to enter the Automatic Mode
- Press and Hold  'Down' until you reach the 'Sensor' menu




- Press  'Enter' to go into the **Sensor menu**
- In the **Sensor Menu** press  **Down** and goto the '**Service Code**' line



- Press  to enter '**Service Code**' line
- Press  **Up** and  **Down** to insert the **received code**
- Once the received code is entered, press  **Enter** to save the code

- Press  'M' to go back to the Sensor Menu.

- To check the code is active; goto **Schultheiss Line** it must be **1i** indicating the code is activated. In the following example the **2:1i** means the second code is activated else it would be **0i**



In case if the problem still exists, please feel free to contact us again.

E-Mail: service@schultheiss-gmbh.de

Schultheiss GmbH